

DUAL-SENSING PROBE THERMOMETER/TIMER

32 to 572°F/0 to 300°C
Counts 10 hours
by minutes & seconds


For roasts
& other meats

- Programmable temperature settings
- Dual progress display
- Distinct alerts for food, oven and timer
- 39" (1 m) high heat sensor cable





Kitchen Measurement Tools



DUAL-SENSING PROBE THERMOMETER/TIMER

32 to 572°F/0 to 300°C
Counts 10 hours by minutes & seconds

GET PROFESSIONAL RESULTS EVERY TIME!

FOOD MODE

Set the temperature alert for USDA safe cooking temperatures — listed on the back of the case! Both the set and actual temperatures are displayed during cooking.

OVEN MODE

For oven testing, the DSP1 measures the ambient temperature of the oven simultaneously and offers distinct alert sound when the set oven temperature is reached.

TIMER MODE

Count up or down with this big digit timer.

Note: Remove label from display before initial use.
Clean the thermometer probe before each use.

Important: DO NOT LEAVE THERMOMETER CASE IN HOT OVEN. CASE IS NOT HEAT RESISTANT. DO NOT USE PROBE IN MICROWAVE OVENS.

MINUTERIE / THERMOMÈTRE À SONDE DOUBLE DÉTECTION

32 à 572°F/0 à 300°C
Compte 10 heures en minutes & en secondes

OBTENIR DES RÉSULTATS PROFESSIONNELS À CHAQUE FOIS !

MODE ALIMENTAIRE

Régler l'alerte de température pour les températures de cuisson sûres d'USDA — affichées derrière le boîtier ! La température réglée et la température actuelle sont affichées pendant la cuisson.

MODE DU FOUR

Pour l'essai du four, le DSP1 mesure simultanément la température ambiante du four et offre une sonnerie d'alerte distincte lorsque la température réglée du four est atteinte.

MODE DE MINUTERIE

Compter progressivement ou à rebours avec cette minuterie numérique à grand chiffre.

Note : Retirer l'étiquette de l'affichage avant la première utilisation. Nettoyer la sonde du thermomètre avant chaque utilisation.

Important : NE PAS LAISSER LE BOITIER DU THERMOMÈTRE DANS UN FOUR CHAUD. LE BOITIER N'EST PAS RESISTANT A LA CHALEUR. NE PAS UTILISER LA SONDE DANS UN FOUR A MICRO-ONDES.

For more detailed information on our products, please visit CDNkitchen.com or call 800-338-5594.



5-Year Limited Warranty: Any instrument that proves to be defective in material or workmanship (excluding batteries) within five years of original purchase will be repaired or replaced without charge upon receipt of the unit prepaid at: CDN, PO Box 10947, Portland, OR 97296-0947 USA. This warranty does not cover damage in shipment or failure caused by failure to adhere to the accompanying instructions, inadequate maintenance, normal wear and tear, tampering, accident, misuse, unauthorized modification, obvious carelessness or abuse. CDN shall not be liable for any consequential or incidental damages whatsoever.



Garantie Limitée de 5 Années: N'importe quel instrument qui se révèle défectueux dans le matériel ou la fabrication (exclusion les piles) au cours de cinq années de l'achat original sera réparé ou remplacé sans charge sur le reçu de l'unité payée d'avance à : CDN, PO Box 10947, Portland, OR 97296-0947 USA. Cette garantie ne couvre pas les dommages causés durant transport ou défaillances causées par le non-respect des instructions d'accompagnement, entretien inadéquat, l'usure normale, altération, accident, mauvaise utilisation, modification non autorisée, la négligence évidente ou abus. CDN ne doit pas être tenu responsable quelque soit les dommages conséquents ou accessoires.

Model/Modèle DSP1

Made in China/Fabrique en Chine
© 04-2019 CDN



0 18436 00455 4